



EV #	Description	Ref Part #	Quantity
-	Gear Housing Complete (1 - 27)	WD 0019	1
1	Adapter	3161 0893 00	1
2	Seal Ring	3161 0852 00	1
3	Screw	0211 1367 00	6
4	Clamp Ring	3161 0619 00	1
5	Seal Ring	3161 0753 00	2
6	Gasket	3161 0622 00	1
7	Gasket	3161 0621 00	1
8	Ball Bearing	0504 0602 00	2
9	Gear Housing	3161 0626 00	1
10	Grease Nipple	0544 2162 00	1
11	Spacer Sleeve	3161 0627 00	1
12	Ball Bearing	0502 2112 00	1
13	Spacer Ring	3161 0630 00	1
14	O Ring	0663 9194 00	1
15	Spring Complete	3161 0628 80	1
16	Spindle	WD 0020	1
17	Bushing	3161 0755 00	1
18	O Ring	0663 3131 00	2
19	Seal Ring	3161 0634 00	1
20	Spring	3161 0635 00	1
21	Parallel Pin	0102 0410 00	2
22	Cover	3161 0631 00	1
-	Insert	WD 0021	6
23	Screw	0147 1407 00	8
24	Plug	0686 6103 00	1
27	Air Inlet Tube	3161 0636 00	1

\* Suffix "M" with the Ref. Part # is **Modified**