



EV #	Description	Ref Part #	Quantity
-	Traction Unit Complete with Air Motor	3163 2425 80	1
1	Lubricating Nipple	WD 0044	1
2	Circlip	0335 1139 00	1
3	Washer	WD 0045	1
4	Spring	3175 0528 00	1
5	Carrier	3175 0529 00	1
6	Screw	3175 0526 00	1
7	Washer	0301 2158 00	1
8	Seal Ring	3163 2492 00	1
9	Bearing Housing	3163 2460 00	1
10	Screw	0211 1363 00	6
11	Spacer Ring	WD 0046	3
12	Ball Bearing	0502 1120 00	1
13	Gear Housing	WD 0047	1
14	Seal Ring	0665 9180 00	1
15	Bushing	3163 2249 00	1
16	Worm Wheel, Complete	9718 4263 80	1
17	Ball Bearing	0502 2115 00	1
18	Spacer Ring	3163 2459 00	1
19	Circlip	0335 2178 00	1
20	Nut	0295 3112 00	1
21	Lock Washer	0333 6112 00	1
22	Circlip	0335 2169 00	1
23	Spacer Ring	3163 2458 00	1
24	Ball Bearing	0502 2111 00	2
25	Spacer Sleeve	3163 2457 00	1
26	Spacer Ring	3163 2456 00	1
27	Seal Ring	3163 2490 00	1
28	Screw	0211 1362 00	4
29	Bearing Housing	3163 2427 00	1
30	Shaft	3163 2445 00	1
31	Screw	0211 1365 00	6
32	Cover	3163 2451 00	1
33	Nut	0295 3108 00	1
34	Lock Washer	0333 6108 00	1
35	Ball Bearing	0504 2107 00	1
36	Bearing Housing	3163 2450 00	1
37	Worm Shaft	9718 4264 00	1
38	Key	0337 7152 00	1
39	Ball Bearing	0506 2108 00	1
40	Spacer Ring	3163 2452 00	1
41	Circlip	0335 1140 00	1
42	Plug	0686 3703 00	1
43	Gasket	0653 9078 00	1
44	Screw	0211 1365 00	3
45	Washer	0301 2144 00	3
46	Gear (51T) (Modified)*	WD 0048 (M)	1
47	Circlip	0335 1136 00	1
48	Motor Casing (Modified)*	WD 0049 (M)	1
49	Screw	0211 1363 00	3
50	Piston Motor Complete - 9 Teeth	4450 0776 80	1
51	Spring Washer	0333 2130 00	4
52	Screw	0211 1363 00	4
53	Bushing	0653 8526 00	1
54	Elbow	0560 1306 00	1

* Suffix "M" with the Ref. Part # is Modified